

Mobile Printer  
**PPT300BT**  
***USER MANUAL***



Rev.1.0

# Caution Symbol



Never touch the thermal head immediately after the printer has been used. Let the thermal head cool for a few minutes before touching it.



This symbol is indicate that it is easily damaged. Observe the precautions for handling electrostatic sensitive devices.

## Safety Precautions

Please be sure to read

To use this product in safety, please follow the precautions given below.

---



### WARNING

- ✓ If you notice smoke, a strange smell, or a strange sound, turn off the power immediately, and remove the USB cable and/or battery pack. Then contact the dealer.
  - ✓ If any foreign material (metal scraps, water, or other fluid) enters the printer, immediately turn off the printer and remove the USB cable and/or battery pack. Then, contact your dealer for advice. Continued use of the printer could result in a fire.
  - ✓ Never attempt to repair the printer yourself. Also do not disassemble or modify the product. Doing so could lead to injury, fire, or electric shock.
  - ✓ Do not touch the tear bar.
    - ← There is a tear bar inside the paper outlet slot. Neither put your hand in the paper outlet slot while printing is in progress, or put your hand into the outlet even when printing is not in progress.
    - ← The printer cover can be opened when replacing the paper. However, since the tear bar is on the inside of the printer cover, be careful not to place your face or hands too close to the tear bar.
  - ✓ During and immediately after printing, the area around the thermal head is very hot. Do not touch it, as you could be burned.
  - ✓ If any battery fluid gets on your skin or clothing, immediately wash the affected area with fresh water. Otherwise, skin damage may result.
  - ✓ The battery pack may be hot immediately after the product has been used.
-

## ■ Using the Printer

- ✓ Some semiconductors can be damaged by static electricity. Be sure to turn off the printer when inserting or removing the battery pack.
- ✓ Do not drop the printer or hit it against a hard object.
- ✓ Do not open the printer cover while the printer is printing.
- ✓ Before you open the printer cover, make sure that printing data is not being sent to the printer.
- ✓ Do not unplug or plug in a USB cable while the printer is printing or during communication.
- ✓ Do not touch a USB connector while the printer is printing.
- ✓ Turn off the printer when you are not using it.
- ✓ When the printer is used in a low temperature environment, the battery's performance will be diminished, and the amount of time that you can use the printer for may be reduced.
- ✓ Do not pull out paper while the printer cover is closed.
- ✓ The heating element and the driver IC of the thermal head are easily damaged. Do not touch them with metal objects, sandpaper, etc.
- ✓ Printing quality may suffer if the thermal head heating element becomes soiled by being touched with your hands. Do not touch the thermal head heating element.
- ✓ There is a risk of damage to the driver IC of the thermal head from static electricity. Never directly touch the IC.
- ✓ Do not operate the printer if there is moisture on the front surface of the head from condensation, etc.

## ■ Thermal Paper Handling

- ✓ Only use thermal paper with the designated specifications. The printing quality and working life of the thermal head cannot be guaranteed if any paper other than that recommended is used. In particular, if ion concentration of  $[Na^+, K^+, Cl^-]$  is high, it may drastically reduce the working life of the thermal head. Please exercise caution.
- ✓ Store the thermal paper in a cool, dry, dark location.
- ✓ Do not rub the thermal paper with a hard object.
- ✓ Do not leave the thermal paper in contact with plastic film, an eraser, or adhesive tape for a long period of time.
- ✓ Do not stack the thermal paper on fresh diazo copies or wet-type copies.
- ✓ Do not use chemical glue on the thermal paper.
- ✓ Do not use thermal paper that has been stored for a long period.

## ■ Operating Environment for the Printer

Before actually unpacking the printer, remember the following points when doing this.

- ✓ Do not use the printer in an environment in which it will be subject to strong shaking while it is printing.
- ✓ Be careful to ensure that the printer is not exposed to direct sunlight.

The appropriate environment for using the printer is described below.

Temperature: -5°C to 50°C

Humidity: 25% RH to 85% RH (no condensation)

- ✓ Do not place the printer near a copying machine or other device that produces a strong electromagnetic field.
- ✓ Keep the printer sufficiently removed from heaters and other sources of heat.
- ✓ Use the printer in a clean, low-humidity environment that is free from dust.
- ✓ Avoid using the printer in high-humidity rooms.

## ■ Printer Maintenance

Please perform the following maintenance every 6 months.

- ✓ Thermal head  
Dip a cotton swab in an alcohol solvent (ethanol, methanol, or isopropyl alcohol), and clean the heating area of the head.
- ✓ Platen  
While turning the platen, use a soft dry cloth to lightly rub the entire surface of the platen and remove any foreign objects.
- ✓ Paper storage unit and the surrounding area  
Remove any dirt, dust, pieces of paper, etc., from the paper storage unit.
- ✓ Card reader  
Regularly blow air onto the card reader to remove any dust from the card slot.

## ■ Using a Magnetic Card

- ✓ Do not bring magnets near the card, and do not store the card near a device that produces a magnetic field (such as a mobile phone, speaker, or TV). If you do so, the data on the card may be deleted.
- ✓ Do not leave the card in a high-temperature environment (such as the dashboard of a car). If you do so, the card may bend.
- ✓ Do not touch the card with dirty or wet hands. Also, do not attach adhesive tape or glue to the card.  
Failing to follow the above precautions could cause the card to stop working properly.

# Contents

|   |    |
|---|----|
| 1. Product Overview.....  | 1  |
| 1.1 Printer & Accessories.....  | 2  |
| 1.2 Appearance and Components.....                                    | 3  |
| 2. Setup.....   | 4  |
| 2.1 Battery Pack.....   | 4  |
| 2.1.1 Inserting into the Printer.....                                 | 4  |
| 2.1.2 Charging the Battery.....                                       | 5  |
| 2.2 Bluetooth.....  | 8  |
| 2.3 Loading Paper.....  | 9  |
| 2.4 Menu Settings.....  | 12 |
| 2.5 Belt Clip.....  | 17 |
| 2.5.1 Install the Belt Clip.....                                      | 17 |
| 2.5.2 Using the Belt Clip.....  | 17 |
| 2. Printer Features.....  | 18 |
| 3.1 Control Panel.....  | 18 |
| 3.1.1 Button.....   | 18 |
| 3.1.2 Panel Lamp.....   | 19 |
| 3.1.3 LCD Indication.....   | 19 |
| 3.1.4 Buzzer Description.....   | 20 |
| 3.2 Self Test.....  | 21 |
| 3.2.1 Self Test Procedure.....  | 21 |
| 3.2.2 Printing the Bluetooth Device Name and Barcode Information..... | 21 |
| 3.3 Instruction for Standby(Sleep) Mode.....                          | 22 |
| 3.4 Magnetic Card Reader.....   | 23 |
| 4. Paper.....   | 25 |
| 4.1 Paper Specification.....  | 25 |
| 4.2 Recommended Paper.....  | 25 |
| 4.3 Printing Range.....   | 25 |
| 4.4 Specification of Black Mark.....                                  | 26 |
| 5. General Specification.....   | 27 |
| 6. Detailed Specification.....  | 30 |
| 7. Interface.....   | 31 |
| 7.1 USB for Battery Charge.....                                       | 31 |
| 7.2 Bluetooth.....  | 32 |
| 8. Specifications of Accessories.....                                 | 33 |
| 8.1 Battery Pack.....   | 33 |
| 8.2 Belt Clip.....  | 33 |

---

|  |    |
|--|----|
| 9. Troubleshooting Procedure.....                              | 34 |
| 9.1 Troubleshooting Guide.....                                 | 35 |
| 9.1.1 Power Supply Failure.....                                | 35 |
| 9.1.2 Printing Failure.....                                    | 35 |
| 9.1.3 Faulty Sensor.....                                       | 36 |
| 9.1.4 Paper Feed Failure.....                                  | 36 |
| 9.1.5 Error Message(Printer Status indication on the LCD)..... | 37 |

This manual supports the following firmware version.

|                  |         |
|------------------|---------|
| Firmware Version | Ver.1.0 |
|------------------|---------|

Refer to the appropriate manual which supports the firmware version of you printer.

The firmware version can be confirmed by the self-test.(Refer to 3.2 Self-test)

---

# 1. Product Overview

This printer is perfect for mobile banking systems, retail, POS (point of sale) terminals and other forms of mobile computing.

The characteristics of this printer are listed below:

- Pocket size (106.2x139.1x61.9mm)
- Extremely light and mobile (400g including Battery pack)
- Very silent printing thru direct thermal printing method
- Print speed max.70mm/s
- Support Bluetooth Ver3.0/4.0[BLE] Dual Mode
- Support Secure Magnetic Stripe Reader <Model with Card Reader>
  - \* AES or 3DES encryption
  - \* DUKPT Key Management
- Support Graphic LCD(128x64 dots) with Blue Backlight
- Belt Clip as a standard accessory
- Support text and graphic printing
- easy to load paper
- A printer cover that can be opened with the touch of a button
- Printer cover open sensor, Paper-out sensor, Black mark sensor, Label gap detection

## 1.1 Printer & Accessories

The printer is packaged with the following accessories.


If any of these accessories is broken or missing, please contact the dealer that you bought the product.



Printer



USB Cable



AC Adapter



Battery Pack



Roll Paper



Belt Clip



Quick Start Guide



CD

*Note:*


*1) The AC adapter vary by local or region.*

*2) The packing materials are actually dependent on the order.*




## 1.2 Appearance and Components


### ■ Front



### ■ Rear



### ■ Inside



## 2. Setup

### 2.1 Battery Pack

#### 2.1.1 Inserting into the Printer

- 1) Make sure that the printer has been turned off before you insert or remove the battery pack.
- 2) Insert the battery pack into the back of the printer as in the figure shown below, following the direction of the arrow. Press down on the battery pack until the hooks click into place.




- 3) To remove the battery back, pull back the hook, and use the opposite procedure from the one you used to insert the battery pack.



## 2.1.2 Charging the Battery

Insert the battery pack into the printer to charge it.

Plug in socket with USB charging.



When battery pack runs out of power, the battery icon will flash. It powers off automatically when continues printing. If you want to go on, please charge it.

Battery charging

- ◆ POWER lamp will always flash in green color and goes off when fully charged.



### **Notes about the Battery Pack**

#### ◆ General Battery Characteristics

- The battery is a consumable and its performance over time gradually decreases.
- While not in use, the battery will slowly discharge itself.  
Prepare a battery pack that has been charged relatively recently (1 to 2 days earlier).
- To ensure that the battery lasts for a long time, we recommend that you turn off the printer whenever possible.
- When used at low temperatures, battery performance will temporarily decline. Be sure to have a fully-charged spare battery standing by if the printer will operate in a cold environment.

---

**◆ Charging the Battery Pack**

- The battery pack can be charged at ambient temperatures between 0 and 40°C.
- The time required to charge the battery pack varies depending on the voltage and the ambient temperature.

Normally, it takes 3 to 4 hours to charge the battery pack.

- It will take longer to charge the battery pack if you print while charging the battery pack.
- Do not remove the battery pack while it is being charged.
- Fully charge the battery prior to using the printer. Otherwise, the performance of the battery may be affected.
- There is no need to completely discharge or use up a rechargeable Lithium-ion battery before recharge it.
- It is normal for the battery pack to be hot after it has finished charging or been used.

**◆ Notes about Using the Battery Pack**

- Only use a designated battery pack.
- Only use the designated battery charging method.

You cannot use a USB cable other than the designated USB cable.

- Do not throw the battery into a fire, place it near a flame or heating device, or leave it in a hot environment (under direct sunlight, in a car, etc.).
- Do not use a battery pack that has been dropped or subjected to a shock in some other way.
- Do not disassemble or modify the battery pack.
- Do not short the terminals of the battery pack or get it wet.
- Do not place the battery pack in a bag with a small metal object (such as a key).
- If any battery fluid gets on your skin or clothing, immediately wash the affected area with fresh water. Otherwise, skin damage may result.

**◆ Notes about Storing the Battery Pack**

- If you do not intend to use the battery pack for a long time, be sure to remove it from the printer.
- Keep the battery out of the reach of children. In addition, be careful that children do not remove the battery.
- Store the battery pack in a cool place.

\* We recommend that you store the battery pack in a dry area with an ambient temperature of 15 to 25 °C.

\* Avoid storing the battery in locations with high or extremely low temperatures.

◆ **Battery Disposal and Recycling**

A battery pack is used to power this device. Since the disposal process of batteries varies from country to country, refer to the appropriate measures mandating the disposal method of the country in which this device is used.


If the battery pack is not in use for a long time, please remove it after fully charged. And it should be recharged every 3 months.

When power is low, battery should be charged in time. If the printer automatically power down because of low power, be sure to charge the battery in 15 days. Otherwise, it will cause permanent damage to the battery.

## 2.2 Bluetooth

1) Press and hold MODE button for approx. 2 seconds, and printer is turned on.

Then, it is ready to pair with another Bluetooth device.



2) If necessary, enter the following information into the terminal that you are using.

PIN: 1234 (default)

Device name: "PPT300BT-XXXXX" (default)

(XXXXX is the last digits of the Product Serial Number)

### Notes:

1. PPT300BT has two Bluetooth modes:

a) One is Bluetooth Ver3.0 with PIN for Android or Windows system. PIN and Device name can be changed through Star Utility. To obtain this utility, please contact with your dealer.

b) Another is Bluetooth 4.0(BLE) without PIN for iOS system.


2. PPT300BT changes the Bluetooth mode automatically by host system.

3. Pairing sets one by one in order, otherwise it can't figure out which one succeeds in pairing.


## 2.3 Loading Paper

Refer to Section 4 “Paper” (p. 25), to select roll paper that conforms to the specifications.


1) Press the cover open button to open the paper cover.




2) Load the roll paper in the orientation shown in the figure below.



3) Pull the end of the roll straight toward you. Then press down on both sides of the printer cover to close it firmly. When you close the printer cover, make sure that it is closed on both sides.



4) Use the tear bar to cut the extra paper.



### CAUTION

When ERROR lamp is flashing, please make sure the cover is closed correctly. If it's not, open the cover and close it correctly.

When the paper is jammed, be sure to open the printer cover before removing the jammed paper.

Do not under any circumstances try to pull out the jammed paper forcefully while the printer cover is closed, doing so may damage parts of the printer.



## Caution Symbol



Never touch the thermal head immediately after the printer has been used.

Also, even when the thermal head is not hot, do not touch it, because static electricity can damage the devices inside the thermal head.

---

### **WARNING**

1) Do not touch the tear bar.


- There is a tear bar inside the paper outlet slot. You could neither put your hand in the paper outlet slot while printing is in progress nor put your hand into the outlet even when printing is not in progress.
- The paper cover can be opened when replacing the paper, be careful not to place your face or hands too close to the tear bar.

2) During and immediately after printing, the area around the thermal head is very hot. Do not touch it, as you could be burned.


## 2.4 Menu Settings

Change the Menu settings by following operations. (Refer to P16 “Menu Setting Table”)

- 1) Press and hold the MODE button for approx. 2 seconds, and printer is turned on.



- 2) Press and hold both the MODE & FEED. Release the buttons after printer displays “Enter Menu Mode”, then you can configure the settings.



- 3) To switch the Menu and option parameter , or return to the previous menu, press MODE button.
- 4) To move the cursor(“\_”), entry the printer mode, or confirm the new setting, press FEED button.

### CAUTION

Before changing the menu setting, make sure that the communication with a host device is disconnected.

When the printer is under the Bluetooth communication with a host device, it cannot enter the Menu Settings mode.

## Example

When you want to change the settings of the printer mode as shown below,

| Item            | Factory Setting | Configuration Example |
|-----------------|-----------------|-----------------------|
| 1 Density       | 0(Medium)       | 1(Low)                |
| 2 Standby Time  | 0060(Sec)       | 0080(Sec)             |
| 3 Auto Off Time | 0120(Min)       | 1120(Min)             |
| 4 Paper Type    | 0(Receipt)      | 2(BM(2inch))          |
| 5 Language      | 0(EN)           | 1(CH)                 |
| 6 Factory Reset | 0(N)            | 1(Y)                  |

Press and hold the MODE & FEED buttons for 5 seconds.

→You will see present “Enter Menu Mode” in the LCD.

Press the MODE button once to switch the menu item.

Display: 1 Self Test →2 System Setting

→Press and hold the FEED button for 2 seconds to get into the menu.

Display: 1 Density  
2 Standby Time  
3 Auto Off Time  
4 Paper Type  
5 Language  
6 Factory Reset  
7 Prior Menu

➤ Press MODE button to switch the menu item, then press the FEED button once to enter the menu.

→Press the FEED button once to get into the Density menu.

Display: Density:  
0-Low 1-Medium  
2-High 1  
3-Special

→Press the MODE button once to input the number 1, then press and hold FEED button to confirm the new setting and return to the previous menu.

1(Medium) → 2(High)

Please use at a room temperature if you want to set the density to ‘3 Special’.  
Some type of the paper are not suitable for use in low temperature environment.



- Press the MODE button 4 times to switch the menu item--Language.

→Press the FEED button once to get into the menu.

Display:                      Language  
                                    0-EN 1-CH

0

- Press the MODE button 5 times to switch the menu item--Factory Reset.

→Press the FEED button once to get into the menu.

Display:                      0-N  
                                    1-Y

0

→When the setting does not need to be reset, press and hold FEED button to return to the previous menu.

- Press the MODE button 6 times to switch the menu item--Prior Menu.

→Press the FEED button once to return to the prior menu.

Display:                      1 Self Test  
                                    2 System Setting  
                                    3 Exit Menu

- Press the FEED button once to enter the menu item--Self Test

Display:                      1 Print  
                                    2 MSR  
                                    3 MSR Key Inject  
                                    4 Hex Dump Mode  
                                    5 Previous Menu

→Press the FEED button once, you will see present "Press Feed To Print" in the LCD, press FEED button, the new settings will be printed.

---

If the settings were not configured correctly, follow the above procedure to configure the settings again.

## Menu Setting Table

| First-level menu | Second-level menu | Third-level menu                                   | Default |
|------------------|-------------------|--|---------|
| 1 Self Test      | 1 Print           | Press Feed To Print                                | --      |
|                  | 2 MSR             | Please Swipe Card.                                 | --      |
|                  | 3 MSR Key Inject  | Please Inject Key                                  | --      |
|                  | 4 Hex Dump Mode   | Hex Dump Mode                                      | --      |
|                  | 5 Previous Menu   | --   | --      |
| 2 System Setting | 1 Density         | 0-Low<br>1-Medium<br>2-High<br>3-Special           | 1       |
|                  | 2 Standby Time    | Standby Time: [0010-9999(Sec)]                     | 60 Sec  |
|                  | 3 Auto Off Time   | Auto Off Time:[0000-9999(Min)]                     | 120 Min |
|                  | 4 Paper Type      | 0-Receipt<br>1-Label<br>2-BM(2inch)<br>3-BM(3inch) | 0       |
|                  | 5 Language        | 0-EN 1-CH  | 0       |
|                  | 6 Factory Reset   | 0-N<br>1-Y   | 0       |
|                  | 7 Prior Menu      | --   | --      |
| 3 Exit Menu      |                   | --   | --      |


NOTE: Please subject to the actual menu setting, this menu setting is only for reference.

## 2.5 Belt Clip

### 2.5.1 Install the Belt Clip


Follow the procedure below to attach the belt clip to the printer.

- 1) Make sure that you are attaching the belt clip in the right orientation, then screw the screw that comes with the belt clip into the designated screw hole to attach the belt clip to the printer.
- 2) Use a screw driver to firmly screw in the screw.



### 2.5.2 Using the Belt Clip

When the printer is attached to your belt, you can use it like the picture below.




*Note: Be careful not to drop when use a belt clip. Velcro be securely fixed.*

Hold the printer firmly with your hand when you swipe a magnetic stripe card or cut paper. If it is not held firmly, you may fail to read card data or cannot cut paper smoothly with the tear bar.

## 2. Printer Features

### 3.1 Control Panel



#### 3.1.1 Button

##### 1) MODE Button:

- ① Pressing and holding the MODE button for 2 seconds or more will turn the power on or off.
- ② Pressing and holding MODE & FEED buttons for 5 seconds will put the printer into Menu Setting mode. The MODE button can now be used to change Printer MODE status visible on the LCD screen for fast configuration.

(Refer to 2.4 Menu Settings for details about mode conversion)

##### 2) FEED Button:

- ① When the printer is on, paper can be feed manually by pressing and holding the FEED button for more than one second.
- ② In Menu Setting mode, the FEED button can be used to move cursor(“\_”) and confirm the new setting.



### 3.1.2 Panel Lamp

- 1) **POWER (Green)**: Printer is ON and ready to receive data.
- 2) **ERROR (Red)**: Indicates an error has occurred. (Eg: Paper Out, Cover Open, etc)

| Power lamp<br>(green) | Error lamp<br>(red) | Status                           |
|-----------------------|---------------------|----------------------------------|
| Flash                 | OFF                 | Power-on charging                |
| Flash                 | OFF                 | Power-off charging               |
| ON                    | OFF                 | Power-on charging, Battery full  |
| ON                    | OFF                 | Power-off charging, Battery full |
| ON                    | OFF                 | Power on                         |
| Flash                 | OFF                 | Standby                          |
| ON                    | Flash               | Paper out                        |
| ON                    | Flash               | Cover open                       |

### 3.1.3 LCD Indication

LCD will display most of the printer status.

- 1) The 128 x 64 dots display shows alphanumeric characters.
- 2) Content

Mode/Status: Indicates the currently specified printer mode or error status.

Remaining battery power:



There is sufficient remaining battery power.



The remaining battery power is low. Please charge the battery pack.



The remaining battery power is extremely low.

**Flashing** Stop using the printer immediately, and charge the battery pack.

Note: If you continue printing at the low remaining battery power status, the printer cannot feed paper properly and may print with condensed (narrow) line spacing.

Bluetooth connection status



The mark on the left indicates that there is no Bluetooth connection.



The mark on the left indicates that there is a Bluetooth connection.

## Paper type



Receipt



Out of paper

### 3.1.4 Buzzer Description

| Buzzer  | Status                                  |
|---------|---|
| No ring | Low battery                             |
| Once    | Begin charging/Press button/Cover close |
| Twice   | Paper out/Cover open                    |
| Three   | USB disconnected                        |

## 3.2 Self Test

You can use self test to check the printer's settings.

Before you start the self test, make sure that roll paper has been properly loaded into the printer.

### 3.2.1 Self Test Procedure

- 1) Turn on the power while holding down FEED button.
- 2) The printer will print the current printer status, including the firmware version, WiFi and Bluetooth information, barcode information.
- 3) The self test will finish automatically. The printer will be ready to receive data after the self test finishes.

### 3.2.2 Printing the Bluetooth Device Name and Barcode Information

Follow the procedure in section 3.2.1 to perform a self test.

```











System : HM-E300
Firmware : 1.00.00 MSR
Build date : Dec 7 2016
Build Time : 14:10:25

S/N: XXXXXXXXXX
PrintDensity : Medium
BatteryVoltage: 8.35 V
StandbyTime : 60 Sec
PowerDownTime : 120 Min
PAPER : Receipt

[Wifi Configure]
Wifi mode : ap
SSID : 8711af_ap
Encryption : 12345678
IP address : 192.168.1.1
Snbnet Mask : 255.255.255.0
MAC Address : a0:2c:36:f8:15

[Bluetooth Configure]
Name : HM-E300
Addr : 34-81-F4-1A-6D-05
Simple Pairing : Disable

[Install Fonts]
ID Font Name
0 SYSTEM 12x24
10 CODEPAGE : PC437[U.S.A., Standard Europe]

[Barcode Samples]
UPCA :

075678 164125
UPCE :

425261
EAN8 :

0421 0009
EAN13:

6901028075831
CODE39:

* 1 2 3 4 5 6 7 8 9 *
ITF :

9 8 7 6 5 4 3 2 1 0
CODABAR:

A 4 0 1 5 6 B
CODE93:

T E S T 9 3
CODE128:

H I S T O R Y
QR code:


[ASCII Samples]
!"#$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNO
PQRSTUVWXYZ[\]^_`abcdefghijklmnopqrstuvwxyz{|}~

Selftest Finished.

```

Self-Test Information

Wifi and Bluetooth Device Name and Font Information

Barcode Information

**NOTE: Please subject to the actual self-test page, this self-test page is only for reference.**

### **3.3 Instruction for Standby(Sleep) Mode**

The printer in the Standby(Sleep) Mode will recover to the Print Ready Mode when receiving print data or button operations.

Press the FEED button or the MODE button and confirm that the LCD is turned on. When the LCD is not turned on, it is possible that the printer is turned off by the Power OFF mode. In this case, turn the printer on manually.

### 3.4 Magnetic Card Reader

Please keep the following points in mind when reading a card.


- Swipe the card with its magnetic stripe side towards the printer.
- Hold the card in the center and swipe it straight at a steady speed in the directions of arrows. You can swipe the card in either direction to read the data.

Be sure to hold the printer firmly with your hand while swiping.

➤ *Pay attention to the hand you hold the printer, your finger should not touch the cover of the MSR slot, if not, the card cannot be read properly. (See correct example on Figure 3.4-2)*

If you hold the corner of the card, it is difficult to swipe it straight so that you may fail to read the card data. So hold the card in the center when you swipe the card.

**Figure 3.4-1**



**Figure 3.4-2**




- A buzzer will sound once when a card is successfully read, and you will see present "MSR read success" in the LCD.
- When the printer fails to read the card, the buzzer will sound three times and you will see present "MSR read failure" in the LCD. Please check the orientation of the card, and slide it through the reader slot again.

**Note:**

- Swiping JIS card is also under MSR mode.**
- JIS card operation is same as MSR card operation.**


## ■ Correct example:



Make sure the magnetic stripe is towards to the magnetic head. Hold the card in the center as illustrated below and swipe it straight at a steady speed in the direction of arrows.

## Incorrect example:

### To grasp a magnetic card



If you grasp the front/rear part of a card and move it through the MSR slot, the front /rear part is loose and a read error occurs.

### To move a magnetic card



If you insert a card tilted upward/downward into the MSR slot, the card does not move horizontally and a read error occurs.



If you extract a card at the end of the MSR slot by lifting up or lowering down, the card is not maintained and a read error occurs.



If you insert a card into the middle part of the MSR card, the card is not read correctly and read error occurs, or if you move the card back or forth by force after inserting into the MSR slot, the card is not read correctly and a read error occurs.

## 4. Paper


### 4.1 Paper Specification

|                     |  |
|---------------------|--|
| Paper type          | Thermal paper                              |
| Paper width         | 80mm                                       |
| Paper thickness     | $0.053\text{mm} \leq X \leq 0.12\text{mm}$ |
| Roll paper diameter | Max.50mm                                   |

### 4.2 Recommended Paper

| Manufacturer                   | Product Name  |
|--------------------------------|---------------|
| Mitsubishi Paper Mills Limited | P220AG        |
| Oji Paper Co., Ltd.            | PD450         |
| Appvion, Inc                   | Alpha 400-2.1 |
| Oji Paper Co., Ltd.            | FD200         |
| Oji Paper Co., Ltd.            | PD160R-63     |

### 4.3 Printing Range



#### CAUTION

- 1) Do not use roll paper whose end is glued to its core, because the printer will be unable to properly detect the end of the paper. Also, we recommend that you use roll paper that has a roll end mark at its end.
- 2) Chemicals and oil may cause the roll paper to change color or cause the printed characters to become lighter.
- 3) Please be aware that the roll paper can be affected by heat, humidity, and direct sunlight.
- 4) The roll paper may change color if you scratch it with your fingernail, a hard piece of metal, etc.





## 5. General Specification

Table 5-1 General Specification

(1/2)

| Item                |                      | Specifications  |  |
|---------------------|----------------------|---|--|
| Printing            | Printing method      | Direct line thermal printing  |  |
|                     | Resolution           | 203dpi (8dots/mm)   |  |
|                     | Printing speed       | Max.70mm/s  |  |
|                     | Valid printing width | 72mm (576dots)  |  |
| Interface           | Bluetooth            | Bluetooth Spec  | Bluetooth Ver 3.0/4.0 [BLE]<br>Dual Mode |
|                     |                      | Frequency range   | 2.4GHz ISM band                          |
|                     |                      | Data transmission rate  | 115200bps adjustable                     |
|                     |                      | Data bit  | 8 data bit fixed                         |
|                     |                      | Parity bit  | No parity fixed                          |
|                     |                      | Stop bit  | 1 stop bit fixed                         |
|                     |                      | SSP   | Compatible                               |
|                     |                      | USB, Bluetooth, Wifi (Optional)   |  |
| Power saving        | Sleep mode           | YES   |  |
| Memory              | Flash                | 4MByte  |  |
| Character Set       | Font                 | Alphanumeric: 9x17, 12x24 dots<br>Kanji:24x24 dots                                  |  |
| Barcode Symbologies | 1D                   | UPC-A, UPC-E, EAN8, EAN13, CODE39, ITF, CODE128, CODE93                             |  |
|                     | 2D                   | QR code, PDF417   |  |
| Graphics            |                      | Support bitmap printing with different density and user defined bitmap printing     |  |
| Detection           | Sensors              | Printer cover open sensor, Paper-out sensor, Black mark sensor, Label gap detection |  |
| LED lamp            | Power lamp           | Green   |  |
|                     | Error lamp           | Red   |  |

**Table 5-1 General Specification(Continued)**

(2/2)

| Item                     |   | Parameter   |
|--------------------------|---|---|
| Charging                 | USB charge<br>Output DC 5V $\overline{\text{---}}$ 1A |   |
| Power supply             | Battery   | 2300mA 7.4V rechargeable battery pack                                   |
|                          | Battery operating time                                | keep working for about 2 hour(printing full lines of characters)        |
| LCD                      |   | 128 x 64 dots with Blue Backlight                                       |
| MSR<br>(Single Head)     | Format  | ISO 7810, ISO 7811, ISO7812 1st, 2nd and 3rd Track/ JISII Track Reading |
|                          | Security  | AES or 3DES encryption. DUKPT Key Management                            |
| Paper                    | Paper type  | Thermal paper   |
|                          | Paper width   | $79.5 \pm 0.5\text{mm}$   |
|                          | Paper thickness                                       | $0.053\text{mm} \leq X \leq 0.12\text{mm}$                              |
|                          | Roll paper diameter                                   | Max.50mm  |
|                          | Recommended paper                                     | P220AG, PD450, FD200, Alpha 400-2.1, PD160R-63                          |
| Physical characteristics | Operation condition                                   | -5°C to 50°C, 25% to 85%RH  |
|                          | Storage condition                                     | -20°C to 60°C, 5% to 95%RH  |
|                          | Dimension   | 106.2(W) x 139.1(D) x 61.9(H)mm   |
|                          | Weight  | 400g (including battery pack)   |
| Reliability              | TPH   | 50km(not more than 12.5% printing density)/100 million pulses           |
| Software                 | Emulation   | ESC/POS   |
|                          | Driver  | Win xp/Win 7/Win 8/Win 10/Linux   |
|                          | SDK   | WinCE, Win Mobile, Android, IOS, Linux                                  |

**WARNING:**


Please use the recommended thermal paper or same quality paper, otherwise it will influence the printing quality and decrease the thermal print head life.

Please use at a room temperature if you want to set the print density to “Special”.

Some types of the paper are not suitable for use in low-temperature environment.

## ■ Dimensions

- External Dimension: 106.2mm (W) x 139.1mm(D) x 61.9mm (H)
- Weight : 400g (including battery pack)




## 6. Detailed Specification

| Item                            | Specification  |
|---------------------------------|--|
| MCU specification               | MCU: 32bits RISC, FLASH : 256K bytes, RAM: 48K Bytes |
| Bluetooth highest frequencies   | 2.4 GHz  |
| Bluetooth module basic clocking | 26MHz  |
| Bluetooth output                | 2.34mW (3.7dBm)                                      |

## 7. Interface


### 7.1 USB for Battery Charge



PPT300BT printer has a USB interface for Battery charging and is connected by means of 5pin micro USB socket. In the following table, the signals present on the micro USB socket are listed.

| Pin No. | SIGNAL |
|---------|--------|
| 1       | VBUS   |
| 2       | D-     |
| 3       | D+     |
| 4       | NC     |
| 5       | GND    |

#### ■ USB cable



## 7.2 Bluetooth

| Category               | Specification                         |
|------------------------|---------------------------------------|
| Bluetooth Spec.        | Bluetooth Ver 3.0/4.0 [BLE] Dual Mode |
| Frequency Range        | 2.4GHz ISM band                       |
| Data Transmission Rate | 115200bps adjustable                  |
| Data Bit               | 8 data bit fixed                      |
| Parity Bit             | No parity fixed                       |
| Stop Bit               | 1 stop bit fixed                      |
| SSP                    | Compatible                            |

PIN code: 1234 as default

Device Name: PPT300BT-XXXXX

(XXXXX is the last 5 digits of the Product Serial Number)

## 8. Specifications of Accessories


### 8.1 Battery Pack

7.4V, 2300mAh

Rechargeable Lithium-ion

Safety Approvals: PSE

### 8.2 Belt Clip



## 9. Troubleshooting Procedure

When a trouble occurs, confirm its phenomenon, locate a defective part in accordance with "9.1 Troubleshooting Guide", and troubleshoot as described below.

**Phenomenon:**

Find a trouble phenomenon in this column. If there are multiple phenomena, take all the corresponding items into consideration. This allows you to specify a hidden defective part.

**Cause:**

Lists as many possible causes as possible. Guess a trouble cause out of them and take its check method to specify the trouble cause.

**Check Method:**

Describes a check method to specify a trouble cause.

**Remedy:**

Troubleshoot by taking a remedy described in this column.

By troubleshooting in accordance with the above-mentioned procedure, you can troubleshoot efficiently with fewer misjudgments.



## 9.1 Troubleshooting Guide

### 9.1.1 Power Supply Failure

| Phenomenon | Cause                        | Check Method           | Remedy                        |
|------------|------------------------------|------------------------|-------------------------------|
| No Power   | The battery is not connected |                        | Connect the specified battery |
|            | The battery is discharged    | Battery level<br>≤7.4V | Charge the battery            |

### 9.1.2 Printing Failure

| Phenomenon                        | Cause   | Check Method   | Remedy   |
|-----------------------------------|---|--|--|
| No printing                       | The roll paper is loaded upside down.             |  | Install the roll paper properly.   |
|                                   | Faulty Main Logic Board Unit.                     |  | Replace the Main Logic Board Unit.   |
|                                   | Faulty connection of the thermal head connector.  | Check connection of the thermal head connector.                      | Connect the thermal head cable to connector properly.                                      |
|                                   | Faulty thermal head.                              |  | Replace the Mechanism Unit.  |
| Partly not printed                | Faulty connection of the thermal head connector.  | Check connection of the thermal head connector.                      | Connect the thermal head cable to connector properly.                                      |
|                                   | Printer cover one side close.                     |  | Close printer cover correctly.   |
|                                   | Faulty thermal head.                              |  | Replace the Mechanism Unit.  |
| Faint printout or uneven printout | Level of battery voltage is low.                  | Check the battery lamp on the LCD.                                   | Charge the battery.  |
|                                   | Printer cover one side close.                     |  | Close printer cover correctly.   |
|                                   | Faulty thermal head.                              |  | Replace the Mechanism Unit.  |
|                                   | Foreign substance is adhered to the thermal head. | Check whether any foreign substance are adhered to the thermal head. | Dip a cotton swab or soft cloth in ethyl alcohol and wipe the foreign substance with them. |
|                                   | Non-recommended paper is used.                    | Check whether the paper being used meets the specification.          | Replace it with the specified paper.   |
|                                   | Faulty mounting of the platen.                    | Check mounting condition of the platen.                              | Mount the platen properly.   |

### 9.1.3 Faulty Sensor

| Phenomenon                         | Cause  | Check Method   | Remedy   |
|------------------------------------|--|--|--|
| Does not detect presence of paper. | Faulty paper sensor.                             | Check whether the ERROR lamp flickers when paper is out.             | Replace the Mechanism Unit.                            |
|                                    | Foreign substance is attached the paper sensor.  | Check whether any foreign substance are adhered to the paper sensor. | Remove the foreign substance.                          |
|                                    | Faulty connection of the paper sensor connector. | Check connection of the paper sensor connector.                      | Connect the paper sensor cable to connector correctly. |

### 9.1.4 Paper Feed Failure

| Phenomenon                            | Cause                                     | Check Method  | Remedy  |
|---------------------------------------|---|---|---|
| Paper is not feed or feed irregularly | The printer cover is not closed properly. |   | Close the printer cover properly.                                     |
|                                       | Faulty connection of the motor connector. | Check connection of the motor connector.  | Connect the motor cable to connector correctly.                       |
|                                       | Defective motor.                          |   | Replace the Mechanism Unit.   |
|                                       | Battery voltage drop.                     | Check the battery display of the LCD.   | Charge the battery.   |
|                                       | Faulty Main Logic Board Unit.             |   | Replace the Main Logic Board Unit.                                    |
|                                       | Faulty mounting of the platen.            | Check mounting condition of the platen.   | Mount the platen properly.  |
|                                       | Paper feed failure.                       | Check whether or not the paper is jamming or torn and caught in the paper path. | Eliminate unnecessary paper in the paper path and set paper properly. |
|                                       | Foreign substance in the gear.            |   | Eliminate the foreign substance.                                      |
|                                       | Broken gear.                              |   | If the gear is broken, replace the Mechanism Unit.                    |

### 9.1.5 Error Message(Printer Status indication on the LCD)

| Message          | Description of failure message        | Remark  |
|------------------|---------------------------------------|---|
| Cover Open       | Printer cover is not closed properly. | Close printer cover properly.                           |
| Out of Paper     | Empty paper.                          | Replace the roll paper.                                 |
| High Temperature | Thermal Head is overheat.             | Is recovered with the automatic which comes to be cool. |